

RV-500 Firmware Update Guide

Step 1 – Format the SD Card

Insert an appropriate SD Card (32Gb or less) into your computer and reformat as follows;

1. Select Start Menu
2. Select My Computer
3. Left click once on the SD Card to highlight
4. Right click once on the SD Card to produce the windows pop up menu
5. Left click on "Format..." from the list and the appropriate pop up window will appear
6. Ensure that the options show the correct capacity for your card
7. Set File system to FAT32 and Allocation unit size to 32 Kilobytes
8. Ensure that Quick Format is ticked
9. Left Click on the Start button at the bottom of the Format window.
10. Once complete, close the Format window.

Step 2 - Download The Firmware

This is downloaded from:

<http://road-view.com/download/#1476088319072-750ea053-1fad>

Step 3 - Transferring The Firmware Update onto the SD Card

With your freshly formatted SD Card in the computer open the file that you downloaded.

Highlight the file, right click on the highlight and select copy.

Go again to your start menu and into my computer and double click on the SD Card so that an empty window appears. Right Click in the window and select paste.

The downloaded file will now appear in the SD Card.

Close all windows and safely eject your SD Card.

Step 4 - Updating Your Camera

1. Turn the camera off and keep off until point 3.
2. Insert the card with the file
3. Power on your camera
4. The camera will go through a series of light flashing sequences while the firmware is downloaded. Once complete, the camera will switch off, then power back on to a standard boot sequence.